

## Schedule 2 – Bus

**Application:**

This schedule applies to buses designed, constructed and used for the transportation of passengers with a designated seating capacity of more than 10, including the driver, but excluding the operation for personal use, and also applies to any trailer towed by a bus.

<b>1. Accessibility Devices</b>	
<b>Defect(s)</b> Accessibility device may not be used if: <ul style="list-style-type: none"> <li>• Alarm fails to operate.</li> <li>• Equipment malfunctions.</li> <li>• Interlock system malfunctions.</li> </ul>	<b>Major Defect(s)</b> <ul style="list-style-type: none"> <li>• Vehicle fails to return to normal level after "kneeling."</li> <li>• Extendable lift, ramp or other passenger-loading device fails to retract.</li> </ul>
<b>2. Air Brake System</b>	
<b>Defect(s)</b> <ul style="list-style-type: none"> <li>• Audible air leak.</li> <li>• Slow air pressure build-up rate.</li> </ul>	<b>Major Defect(s)</b> <ul style="list-style-type: none"> <li>• Pushrod stroke of any brake exceeds the adjustment limit.</li> <li>• Air loss rate exceeds prescribed limit.</li> <li>• Inoperative towing vehicle (tractor) protection system.</li> <li>• Low air warning system fails or system is activated.</li> <li>• Inoperative service, parking or emergency brake.</li> </ul>
<b>3. Cargo Securement</b>	
<b>Defect(s)</b> <ul style="list-style-type: none"> <li>• Insecure or improper load covering.</li> </ul>	<b>Major Defect(s)</b> <ul style="list-style-type: none"> <li>• Insecure cargo.</li> <li>• Absence, failure, malfunction or deterioration of required cargo securement device or load covering.</li> </ul>
<b>4. Coupling Devices</b>	
<b>Defect(s)</b> <ul style="list-style-type: none"> <li>• Coupler or mounting has loose or missing fastener.</li> </ul>	<b>Major Defect(s)</b> <ul style="list-style-type: none"> <li>• Coupler is insecure or movement exceeds prescribed limit.</li> <li>• Coupling or locking mechanism is damaged or fails to lock.</li> <li>• Defective, incorrect or missing safety chain/cable.</li> </ul>
<b>5. Dangerous Goods</b>	
	<b>Major Defect(s)</b> <ul style="list-style-type: none"> <li>• Dangerous goods requirements not met.</li> </ul>
<b>6. Doors and Emergency Exits</b>	
<b>Defect(s)</b> <ul style="list-style-type: none"> <li>• Door, window or hatch fails to open or close securely.</li> <li>• Alarm inoperative.</li> </ul>	<b>Major Defect(s) (Passengers may not be carried.)</b> <ul style="list-style-type: none"> <li>• Required emergency exit fails to function as intended.</li> </ul>
<b>7. Driver Controls</b>	
<b>Defect(s)</b> <ul style="list-style-type: none"> <li>• Accelerator pedal, clutch, gauges, audible and visual indicators or instruments fail to function properly.</li> </ul>	<b>Major Defect(s) (Passengers may not be carried.)</b> <ul style="list-style-type: none"> <li>• Accelerator sticking and engine fails to return to idle.</li> </ul>
<b>8. Driver Seat</b>	
<b>Defect(s)</b> <ul style="list-style-type: none"> <li>• Seat is damaged or fails to remain in set position.</li> </ul>	<b>Major Defect(s)</b> <ul style="list-style-type: none"> <li>• Seatbelt or tether belt is insecure, missing or malfunctions.</li> </ul>

<b>9. Electric Brake System</b>	
<b>Defect(s)</b> <ul style="list-style-type: none"> <li>Loose or insecure wiring or electrical connection.</li> </ul>	<b>Major Defect(s)</b> <ul style="list-style-type: none"> <li>Inoperative breakaway device.</li> <li>Inoperative brake.</li> </ul>
<b>10. Emergency Equipment &amp; Safety Devices</b>	
<b>Defect(s)</b> <ul style="list-style-type: none"> <li>Emergency equipment is missing, damaged or defective.</li> </ul>	
<b>11. Exhaust System</b>	
<b>Defect(s)</b> <ul style="list-style-type: none"> <li>Exhaust leak.</li> </ul>	<b>Major Defect(s)</b> <ul style="list-style-type: none"> <li>Leak that causes exhaust gas to enter the occupant compartment.</li> </ul>
<b>12. Exterior Body and Frame</b>	
<b>Defect(s)</b> <ul style="list-style-type: none"> <li>Insecure or missing body parts.</li> <li>Insecure or missing compartment door.</li> <li>Damaged frame or body.</li> </ul>	<b>Major Defect(s)</b> <ul style="list-style-type: none"> <li>Visibly shifted, cracked, collapsing or sagging frame member(s).</li> </ul>
<b>13. Fuel System</b>	
	<b>Major Defect(s)</b> <ul style="list-style-type: none"> <li>Missing fuel tank cap.</li> <li>Insecure fuel tank.</li> <li>Dripping fuel leak.</li> </ul>
<b>14. General</b>	
	<b>Major Defect(s)</b> <ul style="list-style-type: none"> <li>Serious damage or deterioration that is noticeable and may affect the vehicle's safe operation.</li> </ul>
<b>15. Glass and Mirrors</b>	
<b>Defect(s)</b> <ul style="list-style-type: none"> <li>Required mirror or window glass fails to provide the required view to the driver as a result of being cracked, broken, damaged, missing or maladjusted.</li> <li>Required mirror or glass has broken or damaged attachments onto vehicle body.</li> </ul>	<b>Major Defect(s)</b> ( <i>Passengers may not be carried.</i> ) <ul style="list-style-type: none"> <li>Driver's view of the road is obstructed in the area swept by the windshield wipers.</li> </ul>
<b>16. Heater/Defroster</b>	
<b>Defect(s)</b> <ul style="list-style-type: none"> <li>Control or system failure.</li> </ul>	<b>Major Defect(s)</b> <ul style="list-style-type: none"> <li>Defroster fails to provide unobstructed view through the windshield.</li> </ul>
<b>17. Horn</b>	
<b>Defect(s)</b> <ul style="list-style-type: none"> <li>Vehicle has no operative horn.</li> </ul>	

<b>18. Hydraulic Brake System</b>	
<b>Defect(s)</b>	<b>Major Defect(s)</b>
<ul style="list-style-type: none"> <li>• Brake fluid level is below indicated minimum level.</li> <li>• Parking brake is inoperative.</li> </ul>	<ul style="list-style-type: none"> <li>• Brake boost or power assist is not operative.</li> <li>• Brake fluid leak.</li> <li>• Brake pedal fade or insufficient brake pedal reserve.</li> <li>• Activated (other than ABS) warning device.</li> <li>• Brake fluid reservoir is less than ¼ full.</li> </ul>
<b>19. Lamps and Reflectors</b>	
<b>Defect(s)</b>	<b>Major Defect(s)</b>
<ul style="list-style-type: none"> <li>• Required interior lamp does not function as intended.</li> <li>• Required reflector is missing or partially missing.</li> <li>• Passenger safety or access lamp does not function.</li> </ul>	<p><i>When lamps are required:</i></p> <ul style="list-style-type: none"> <li>• Failure of both low-beam headlamps.</li> <li>• Failure of both rearmost tail lamps.</li> </ul> <p><i>At all times:</i></p> <ul style="list-style-type: none"> <li>• Failure of a rearmost turn-indicator lamp.</li> <li>• Failure of both rearmost brake lamps.</li> </ul>
<b>20. Passenger Compartment</b>	
<b>Defect(s)</b>	<b>Major Defect(s)</b>
<ul style="list-style-type: none"> <li>• Stanchion padding is damaged.</li> <li>• Damaged steps or floor.</li> <li>• Insecure or damaged overhead luggage rack or compartment.</li> <li>• Malfunction or absence of required passenger or mobility device restraints.</li> <li>• Passenger seat is insecure.</li> </ul>	<p><i>When affected position is occupied:</i></p> <ul style="list-style-type: none"> <li>• Malfunction or absence of required passenger or mobility device restraints.</li> <li>• Passenger seat is insecure.</li> </ul>
<b>21. Steering</b>	
<b>Defect(s)</b>	<b>Major Defect(s)</b>
<ul style="list-style-type: none"> <li>• Steering wheel lash (free-play) is greater than normal.</li> </ul>	<ul style="list-style-type: none"> <li>• Steering wheel is insecure, or does not respond normally.</li> <li>• Steering wheel lash (free-play) exceeds required limit.</li> </ul>
<b>22. Suspension System</b>	
<b>Defect(s)</b>	<b>Major Defect(s)</b>
<ul style="list-style-type: none"> <li>• Air leak in air suspension system.</li> <li>• Broken spring leaf.</li> <li>• Suspension fastener is loose, missing or broken.</li> </ul>	<ul style="list-style-type: none"> <li>• Damaged, deflated air bag.</li> <li>• Cracked or broken main spring leaf or more than one broken spring leaf.</li> <li>• Part of spring leaf or suspension is missing, shifted out of place or in contact with another vehicle component.</li> <li>• Loose U-bolt.</li> </ul>
<b>23. Tires</b>	
<b>Defect(s)</b>	<b>Major Defect(s)</b>
<ul style="list-style-type: none"> <li>• Damaged tread or sidewall of tire.</li> <li>• Tire leaking.</li> </ul>	<ul style="list-style-type: none"> <li>• Flat tire.</li> <li>• Tire tread depth is less than wear limit.</li> <li>• Tire is in contact with another tire or any vehicle component other than mud-flap.</li> <li>• Tire is marked "Not for highway use".</li> <li>• Tire has exposed cords in the tread or outer side wall area.</li> </ul>

<b>24. Wheels, Hubs and Fasteners</b>	
<b>Defect(s)</b>	<b>Major Defect(s)</b>
<ul style="list-style-type: none"> <li>• Hub oil below minimum level. (When fitted with sight glass.)</li> <li>• Leaking wheel seal.</li> </ul>	<ul style="list-style-type: none"> <li>• Wheel has loose, missing or ineffective fastener.</li> <li>• Damaged, cracked or broken wheel, rim or attaching part.</li> <li>• Evidence of imminent wheel, hub or bearing failure.</li> </ul>
<b>25. Windshield Wiper/Washer</b>	
<b>Defect(s)</b>	<b>Major Defect(s)</b>
<ul style="list-style-type: none"> <li>• Control or system malfunction.</li> <li>• Wiper blade damaged, missing or fails to adequately clear driver's field of vision.</li> </ul>	<p><i>When necessary for prevailing weather condition.</i></p> <ul style="list-style-type: none"> <li>• Wiper or washer fails to adequately clear driver's field of vision in area swept by driver's side wiper.</li> </ul>